




**CECILWARE– Wall Shelf
#430 Stainless Steel**

Assembly Instructions:

**WS-4-24-BS, WS-4-36-BS, WS-4-48-BS,
WS-4-60-BS, WS-4-72-BS & WS-4-24-MW**

Cecilware Corporation
43-05 20th Avenue
Long Island City, NY 11105
Tel: 800-935-2211
Fax: 718-932-7860
www.cecilwarephotos.com

Section 1



Parts List- See Section 1

- a. 1 Stainless Steel Wall Shelf Top
- b. 2 Stainless Steel Wall Shelf Supports

Assembly - See Section 2

- Carefully remove all of the parts from the carton.
- Insert two wall shelf supports into the wall shelf top.
- Use holes on wall shelf as well as shelf support to mount complete wall shelf.
- Before using the wall shelf, we recommend that you clean it thoroughly using a cleaning agent recommended for stainless steel, ensuring all cleaning agents and moisture are removed from the wall shelf before use.


Care of the Wall Shelf

- Clean the wall shelf regularly as required, using a cleaning agent recommended for stainless steel surfaces.
- Always clean off any cleaning solution residue, as failure to do so may cause discolouring and marks to develop.
- Never leave any surface with water or damp areas, as this may cause discolouration.

Warning

- Whilst Cecilware attempts to remove all sharp edges, care must be taken when cleaning or handling the wall shelf to prevent the risk of injury from exposed metal edges.
- Do not overload the wall shelf.

Section 2



Cecilware Corporation

43-05 20th Avenue
Long Island City, NY 11105
Tel: 800-935-2211
Fax: 718-932-7860
www.cecilwarephotos.com